


Outdoor Smart Wireless Floodlight Camera

Quick Start Guide




Model: CSH-FLDLCAM

Welcome

Thank you for choosing our Floodlight Camera. Getting started is easy.

1. What's Included



2. Shut off the power



Turn off the power before installing the floodlight camera.



WARNING: Risk of electrical shock

- Turn off and disconnect the power before installing.
- Verify that the supply voltage is correct. Connect fixture to a AC100V-240V, 50/60 Hz power source.

CAUTION: Risk of fire


• Do not install near combustible or flamable surfaces.

NOTICE

- Do not connect this light fixture to a dimmer switch or timer.
- Floodlight Cam must be installed on a wall and on a UL listed junction box.


3. How it fits all together


Australia gauge power cord color: Blue , Brown, Yellow green. Connect Floodlight Camera cables to a normal socket.



4. Prepare your Floodlight Camera for installation

Loosen the knobs on the light fixtures to rotate them out of the way and allow access to the mounting screws.






According to your actual scene to adjust the view angle of camera






5. Connect the power to the camera

After installation, switch on the button.



6.Connection Preparation

Please install the Floodlight Camera within WiFi covered area to ensure the best working performance.



Note: Make sure smart phone is connected with your wireless router. Please note the camera is only working under 2.4G Wi-Fi and does not support 5g Wi-Fi.

7. Get the APP and Account

For the best experience, please download the 'Connect Smarthome' APP to your smartphone from App Store or Google Play, or you can also scan the QR code below, the APP icon will be displayed after installed successfully.











Launch the app from your smartphone and click the Sign Up button. Follow the on-screen instructions.

8.Set up your camera

- Power the device on and make sure the indicator is red and flashing quickly or a prompt tone is heard
- If the indicator is not red and flashing quickly, use the Reset Needle to press the reset button of camera above 5 seconds, then release the button, a red LED on the front of camera will blink quickly.
- Follow App's instructions to add a new device, Security & Sensor -> Smart Camera. Follow the on screen instruction. The device will connect to your Wi-Fi network successfully.
- The blue light is on, camera is ready for viewing.










You're done!

Congratulations! Your camera is set up and ready to go.





Appendix: Camera LED Guide

NO.	LED Status	Camera Status
1	Red LED on	System starting up
2	Red LED blinks	Standby for configuration
3	Blue LED blinks	Network pairing
4	Blue LED on	Camera online



All trademarks are used for reference purposes only.

Thanks again for choosing our Floodlight camera!

WARRANY AGAINST DEFECTS

Laser Corporation Pty Ltd ("Laser") warrants your new product to be free from defects in materials and workmanship for 12 months, from the date of purchase, provided that the product is used in accordance with accompanying recommendations or instructions where provided. The benefit of this warranty is in addition to your rights under the Australian Consumer Law and to other rights and remedies of the consumer under a law in relation to the goods or services to which the warranty relates.

Through a network of retailers and resellers, Laser will provide you with your choice of a refund, repair or exchange (where possible) for this product if it becomes defective within the warranty period. This warranty will no longer apply where the defect is a result of alteration, accident, misuse, abuse, normal wear and tear, neglect or improper storage.

Please retain your receipt as proof of purchase

How to make a product warranty claim:

Step 1: Find your receipt which proves the date of purchase. Where the date of purchase cannot be verified, your place of purchase or Laser will make an assessment based on the date of manufacture, the condition of the Laser Product and the type of defect.

Step 2a): Contact your place of purchase. They will assess the nature of the fault and refund or replace the product as per their store refund or warranty policy.

Step 2b): If your place of purchase cannot be contacted, then you can contact Laser. Customer Service with details of your defective Laser Product: Phone: (02) 9870 3388; or Email: support@laserco.com.au or online www.laserco.com.au/warranty (click on

"Consumers (End Users)"). Our business address is at 1/6-8 Byfield Street, North Ryde, NSW 2113

WARRANTY AGAINST DEFECTS

Step 3: Laser will issue you with a Return Authorisation (RA) number within 48 hours. When requested, send us the defective Product and a copy of your receipt. Laser will cover the cost of the return delivery.

Step 4: Wait for us to contact you. Once we have received your defective Laser Product for inspection, we will inform you of our assessment of your claim within 7 days. When we contact you, we will firstly let you know whether you have a valid claim under this Warranty, and if so, we will inform you whether your defective Laser Product will be replaced or repaired, together with the number of days you can expect to wait to receive your replaced or repaired Laser Product.

Our goods come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or refund for a major failure and compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure.